ASSEMBLY INSTRUCTIONS

WIRE SHELVING HEAVY DUTY QUICK ADJUST SHELF CONFIGURATION

Use Traditional Shelves at the top and bottom with Quick Adjust Shelves in the middle for increased flexibility.



WIRE SHELVING ASSEMBLY INSTRUCTIONS

TRADITIONAL SHELVES



If you are using Quick Adjust Shelves, use Traditional Shelves at the top and bottom

,,,,,,,,,,,,,,,,,

1. Identify the top and bottom ends of the four poles. The top ends have black plastic caps. The bottom ends have threaded holes. If you are using Quick Adjust shelves, make sure the slots in the poles are facing inward.

2. Select the desired height for the bottom shelf. Please note that the bottom shelf should never be higher than 12" above the floor. Shelves can be placed at any of the 1" circular grooves along the poles. Now take a pair of "slip sleeves" and snap it onto the groove you have selected with the small opening side up.

3. Hold the shelf on its side, slide the top part of the pole from bottom of the shelf through one of the corner holes. The pole "slip sleeves" will slide nicely into the shelves creating a "double wedge." Please note that the wire surface is on top of the shelf. To level, adjust the leveler feet on the bottom of each pole.



CAUTION:

-DO NOT STAND ON OR CLIMB ON SHELVES. -DO NOT DROP HEAVY ITEMS ON THE SHELVES. -PLACE HEAVIER ITEMS ON LOWER SHELVES AND LIGHTER ONES ON TOP. -DO NOT MOVE SHELVES WHILE LOADED.



WIRE SHELVING ASSEMBLY INSTRUCTIONS

QUICK ADJUST SHELVES





Attaches top post with plastic sleeves.

Only use Quick Adjust shelves in the middle of shelving unit

QUICK ADJUST SHELVES

Attaches to post with metal brackets.

2 SHELF RESTS HERE INSERT HANGERS INTO SLOT IN THIS DIRECTION

1. Attach Traditional Shelves to top and bottom first (see previous page)

2. Select the desired height from bottom shelf and insert the four Shelf Hangers into the slotted uprights. Make sure the slotted holes on the posts are facing inward.

3. Clip the shelf onto the shelf hangers.





